



Dimensions

dim.a (A)	length (L)	fall (S)
100	400	300
150	400	300
200	400	300
250	400	300
300	500	300
350	500	300
400	600	400
450	600	400
500	600	400
600	700	400
700	800	500
800	900	500
900	1000	500
1000	1100	500
1100	1200	500
1200	1300	500

Description

Offset rectangular ducts (ORD) are usually used for changing the height of the system on exact point.

For example, when it's needed to go around some element of the system, or other obstacles.

There are some specific requirements for saving necessary level of the air flow that's why it's recommended to use standard length and fall dimensions.

Order example:

ORD - aaa*bbb - lll - sss

type _____

dimensions(A*B) _____

length (L) _____

fall (S) _____